



**1**

**2**

**3**

**Fastening of top track**  
(countersink holes to prevent protrusion of screw head)

Positoner for top carriage **FIX**

**important dimension**

**Door filling:**  
16 mm or 18 mm board

**Max. weight**  
of 50 kg per door

**up to 7 mm**

**ATTENTION**  
When installing the fixed mounting, it is important to situate axis L parallel to axis K (L || K)

**milled pocket**

hole depth 5 mm

**ATTENTION:**  
For fast and accurate routing of the bottom carriage pockets we recommend using template for bottom carriage WD18 HI-TEC index 20191

**Installation of bottom track Gemini-Decor II** using our mounting bush

**Fastening of bottom track** (countersink holes to prevent protrusion of screw head)

**Option: bottom track ELEGANT II**

**With BETA, FOCUS set you may use bottom track Elegant II with covering strip along with bottom carriage WD 18V HI-TEC. Fitting measurements are not affected.**

**Fastening of bottom track** (special screw)


Stopper **HI-TEC**

**COMPONENTS**

<p><b>Handle</b></p> <p>L: 2.70 m</p> <p>BETA C #16, #18      FOCUS #16, #18</p>	<p><b>Top track Gemini-Decor</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>76 mm</p>	<p><b>Bottom track Gemini-Decor II</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>53 mm</p>	<p><b>Bottom carriage WD18V HI-TEC</b></p>
<p><b>Guiding carriage Focus</b></p>	<p><b>Angle section Mini 11 mm x 17 mm</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m</p>	<p><b>Bottom carriage WD18C HI-TEC</b></p>	



Dimensions of opening





Handle length = door height

		BETA C				FOCUS			
		anti-dust brushes (self-adhesive) 6.7 mm x 13 mm textile door stop (self-adhesive) 4.8 mm x 4 mm #16, #18				anti-dust brushes (self-adhesive) 6.7 mm x 13 mm textile door stop (self-adhesive) 4.8 mm x 4 mm #16, #18			
door height	- h	h = H - 42 mm				h = H - 42 mm			
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	h = H - 42 mm			Mini SV25/40/60 SV-25/50	h = H - 42 mm		
		Top SV60/80, Central SV25/40	h = H - 44 mm			Top SV60/80, Central SV25/40	h = H - 44 mm		
board height	- hb	hb = h - 2 mm				hb = h - 2 mm			
door width	- w	w = (W - 3 mm + Z) : N				w = (W - 3 mm + Z) : N			
board width	- wb	wb = w - 3 mm				wb = w - 3 mm			
angle section length	- la	la = w - 32,5 mm				la = w - 58 mm			

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	29 mm	58 mm	87 mm	116 mm	30 mm	60 mm	90 mm	120 mm

visual design – 4 wings									
		w = (W - 3 + 87) : 4				w = (W - 3 + 90) : 4			
		w = (W : 2 + 26) : 2				w = (W : 2 + 27) : 2			

**ATTENTION!**



Handle profile should be 2 mm longer than board height.

**WARNING**


SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

**BETA C**



Installation method for handle and guiding carriage with # 16 mm or # 18 mm board



Installation method for angle section MINI 11 x 17 mm

**FOCUS**

Installation method for handle and guiding carriage with # 16 mm or # 18 mm board



Installation method for angle section MINI 11 x 17 mm



- When fitting handle profiles, do not use assembly adhesive

